TOP AND CONSOLE PARTS

For Models: LGT7646EQ2, LGT7646EZ2
(Designer White) (Designer Almond)

GAS DRYER



WIRING HARNESS PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LGT7646EQ2, LGT7646EZ2
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	3400859	Screw, Grounding
3	3394427	Clip, Harness
4		Cap, End (L.H.)
	3358528	White
	3358529	Almond
5	3397269	Connector (Timer)
7	3395683	Housing, Connector (Motor)
8		Cap, End (R.H.)
	3358513	White
	3358514	Almond
9	694419	Buzzer, Mini
10	349639	Handle & Lint Screen Assembly
11		Cover, Lint Screen
	688150	White
	689310	Almond
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14		Wire, Jumper
	3393811	Violet
	3393812	Blue
	3401667	White
15	693995	Screw, Hex Head
16		Top
	3396022	White
	3396023	Almond
17		Wire, Jumper
	3401684	Black
	3401666	Yellow
18		Switch, Clean Touch
	3406000	White
	3406001	Almond
21	3976580	Timer Assembly (60 Hz.)
22	3403499	Connector, 2−Position (Gas Valve)
23	3403498	Connector, 3−Position (Gas Valve)
29	3390646	Screw, 8−18 x 5/16
30	357213	Nut, Push−In (2)
31	3394301	Harness, Wiring
39	3398095	Relay, Push−To−Start
40	3401144	Connector (PTS Relay)
48		Timer Knob Assembly
	3406143	White
	3406144	Almond
49		Knob, Control
	3950759	White
	3950760	Almond
50	717252	Receptacle, 2−Way
52	94614	Terminal
53	8054300	Bracket, Control
54		Panel, Control
	3976758	White
	3976759	Almond
70	3936144	Connector
76	388326	Screw, Console

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

Illus. No.	Part No.	DESCRIPTION
	LIT3405338	Instructions, Installation
	LIT3406071	Use & Care Guide
	LIT3406692	Label, Wiring Diagram

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

Illus. No.	Part No.	DESCRIPTION
	72017	White
	72107	Almond

PAINT, PRESSURIZED SPRAY (13 oz.)

Illus. No.	Part No.	DESCRIPTION
	350930	White
	350956	Almond
	350938	Primer, Gray

PAINT, BULK (1 qt.)

Illus. No.	Part No.	DESCRIPTION
	799344	White (Uncut)
	978883	Almond (Uncut)

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

Illus. No.	Part No.	DESCRIPTION
	LIT677818	Dryer

CABINET PARTS

For Models: LGT7646EQ2, LGT7646EZ2

(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LGT7646EQ2, LGT7646EZ2
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10−32 x 1/2 (External Ground)
2	343641	Screw, 10−16 x 1/2
3	3404162	Clamp, Motor (W/Shield)
4	238614	Bumper
5	3396795	Cover, Block
6	693995	Screw, Hex Washer Head
7	3396805	Panel, Rear
10	3406101	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
13	694091	Screw, 8−15 x 3/8
14	692495	Spring, Door (2)
15	3357011	Screw, 10−16 x 1/2
16	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2 (Not Included)
18		Cabinet (Inclues Illus. No's. 5, 7, 16, 29 & 57)
	3399585	White
	3399586	Almond
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21		Panel Front
	3395197	White
	3395198	Almond
23	685203	Clip, Felt Pad (2)
24	3398175	Catch, Door Assembly
25	3390731	Seal, Door
26	337189	Clip, Hinge (2)
27	342043	Screw
28	692498	Hinge, R.H.
	692501	Hinge, L.H.
29	3394083	Clip, Front Panel
33	696144	Strike, Panel
35	695737	Door, Rear
36		Door, Front
	3393549	White
	3393550	Almond
37		Handle, Door
	690270	White
	690271	Almond
38	3406129	Seal & Bearing Assembly
45	344020	Cord, Power
49		Plug, Front Panel
	3394975	White
	3394976	Almond
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	3401143	Pulley, 60 Hz.
62	3395652	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3401775	Valve, Gas 60 Hz. (Complete)
65	686590	Ignitor
66	3393909	Lock Screw & Washer (8−32 x 5/8)
67	3402844	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)
68	341029	Clamp, Pipe
69	694572	Kit, Conversion Type 1, 2 & 3 To Type 4 (LPG)
70	694539	Coil, 60 HZ. Split (3 Terminal) (Pilot Position)
71	694540	Coil, 60 HZ. (2 Terminal) (Main)
72	694421	Screw, Bracket Mounting (8−32 X 1/2) 2
73	694538	Bracket, Coil
74	694424	Leak Limiter
75	694423	Screw, Regulator Adjustment
76	694422	Spring, Regulator
79	239822	Plug, Pipe

BULKHEAD PARTS

For Models: LGT7646EQ2, LGT7646EZ2
(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGT7646EQ2, LGT7646EZ2
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8 x 3/8
6	3404232	Bracket, Drum Light
7	3392519	Fuse, Thermal
9	3387134	Thermostat, Internal−Bias
10	694089	Wheel, Blower (Includes Illus. No. 21)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	685458	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	348484	Support, Heater Box
17	348516	Collar, Funnel
18	347389	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	3394196	Seal, Blower
22	3402729	Lens, Drum Light
23	487909	Screw
24	3406022	Bracket, Bulkhead
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3403493	Bulkhead
49	338906	Sensor, Radiant
62	692526	Ring, Bearing
63	97787	Screw, 11−16 x 7/8
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust

3402844 BURNER ASSEMBLY

For Models: LGT7646EQ2, LGT7646EZ2
(Designer White) (Designer Almond)

USE WITH TYPE 1 − NATURAL, TYPE 2 − MIXED, TYPE 3 − MANUFACTURED AND TYPE 4 − LIQUEFIED PROPANE AND BUTANE GASES



3402844 BURNER ASSEMBLY

For Models: LGT7646EQ2, LGT7646EZ2

(Designer White) (Designer Almond)

USE WITH TYPE 1 − NATURAL, TYPE 2 − MIXED, TYPE 3 − MANUFACTURED AND TYPE 4 − LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	3402844	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 5/8)
6	343641	Screw, 10−16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8−18 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	3406052	Elbow Union Assembly
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.

BA−141